

■ 普通旋转 RC接头 (直通型式)



[型号代码说明]:  
(空白) 黄铜镀镍+PBT

型号选择		插管口径D (mm/inch)	安装螺纹T (M/PT/NPT)
型号	可选代码		
RC4-M5		4	M5
RC4-M6		4	M6
RC4-01		4	R1/8
RC6-M5		6	M5
RC6-M6		6	M6
RC6-01		6	R1/8
RC6-02		6	R1/4
RC8-01		8	R1/8
RC8-02		8	R1/4
RC8-03		8	R3/8
RC10-01		10	R1/8
RC10-02		10	R1/4
RC10-03		10	R3/8
RC10-04		10	R1/2
RC12-02		12	R1/4
RC12-03		12	R3/8
RC12-04		12	R1/2
RC1/4-01	(空白)	1/4	R1/8
RC1/4-02		1/4	R1/4
RC5/16-01		5/16	R1/8
RC5/16-02		5/16	R1/4
RC5/16-03		5/16	R3/8
RC3/8-03		3/8	R3/8
RC3/8-04		3/8	R1/2
RC5/32-N1U		5/32	NPT1/8
RC3/16-N1U		3/16	NPT1/8
RC3/16-N2U		3/16	NPT1/4
RC1/4-N1U		1/4	NPT1/8
RC1/4-N2U		1/4	NPT1/4
RC5/16-N1U		5/16	NPT1/8
RC5/16-N2U		5/16	NPT1/4
RC5/16-N3U		5/16	NPT3/8
RC3/8-N3U		3/8	NPT3/8
RC3/8-N4U		3/8	NPT1/2
RC1/2-N3U		1/2	NPT3/8
RC1/2-N4U		1/2	NPT1/2

■ 普通旋转 RL接头 (普通L型式)



[型号代码说明]:  
(空白) 黄铜镀镍+PBT

型号选择		插管口径D (mm/inch)	安装螺纹T (M/PT/NPT)
型号	可选代码		
RL4-M5		4	M5
RL4-M6		4	M6
RL4-01		4	R1/8
RL6-M5		6	M5
RL6-M6		6	M6
RL6-01		6	R1/8
RL6-02		6	R1/4
RL8-01		8	R1/8
RL8-02		8	R1/4
RL8-03		8	R3/8
RL10-01		10	R1/8
RL10-02		10	R1/4
RL10-03		10	R3/8
RL10-04		10	R1/2
RL12-02		12	R1/4
RL12-03		12	R3/8
RL12-04		12	R1/2
RL1/4-01	(空白)	1/4	R1/8
RL1/4-02		1/4	R1/4
RL5/16-01		5/16	R1/8
RL5/16-02		5/16	R1/4
RL5/16-03		5/16	R3/8
RL3/8-03		3/8	R3/8
RL3/8-04		3/8	R1/2
RL5/32-N1U		5/32	NPT1/8
RL3/16-N1U		3/16	NPT1/8
RL3/16-N2U		3/16	NPT1/4
RL1/4-N1U		1/4	NPT1/8
RL1/4-N2U		1/4	NPT1/4
RL5/16-N1U		5/16	NPT1/8
RL5/16-N2U		5/16	NPT1/4
RL5/16-N3U		5/16	NPT3/8
RL3/8-N3U		3/8	NPT3/8
RL3/8-N4U		3/8	NPT1/2
RL1/2-N3U		1/2	NPT3/8
RL1/2-N4U		1/2	NPT1/2

