

■ 真空过滤器（大容量-管路连接型式）



型号选择	D1 (mm)	D2 (mm)	过滤面积 (cm <sup>2</sup> )	
FVFR20-6-6	6	6	20	
FVFR20-8-8	8	8	20	
FVFR20-10-10	10	10	20	
FVFR20-12-12	12	12	20	
FVFR20-16-16	16	16	20	

■ 真空过滤器（大容量-排入大气型式）




型号选择	D1 (mm)	D2 (mm)	过滤面积 (cm <sup>2</sup> )	
FVFR20-6	6	6	20	
FVFR20-8	8	8	20	
FVFR20-10	10	10	20	
FVFR20-12	12	12	20	
FVFR20-16	16	16	20	

■ 真空过滤器（大容量-平面连接型式）



型号选择	D1 (mm)	D2 (mm)	过滤面积 (cm <sup>2</sup> )	
FVFB20-6-6	6	6	20	
FVFB20-8-8	8	8	20	
FVFB20-10-10	10	10	20	
FVFB20-12-12	12	12	20	
FVFB20-16-16	16	16	20	

[使用范例1]:



[使用范例2]:

