


■ 内接头 (PM外螺纹安装式)




[型号代码说明]:

-T 钢铁(镀镍)

型号选择		螺纹T	L (mm)	d (mm)	
型号	可选代码				
QTS-10PM		R1/8	57.5	4	
QTS-20PM	-T	R1/4	60	8	
QTS-30PM		R3/8	60	10	


■ 内接头 (PFF内螺纹安装式)



[型号代码说明]:

-T 钢铁(镀镍)

型号选择		螺纹T	L (mm)	d (mm)	
型号	可选代码				
QTS-20PFF	-T	G1/4	(59)	7	



▲ 气动工具

