


■ 透气柱（圆孔式） P04-R503



[单位: mm]

型号选择		D	L	h	d					
型号	微孔选择									
P04-R50304	01 02 03	4	10	7	2					
P04-R50305	01 02 03	5	10	7	2					
P04-R50306	01 02 03	6	10	7	3					
P04-R50308	01 02 03	8	10	7	4					
P04-R50310	01 02 03	10	10	7	6					
P04-R50312	01 02 03	12	12	8	6					
P04-R50316	01 02 03	16	14	10	8					
P04-R50318	01 02 03	18	16	11	10					
P04-R50320	01 02 03	20	16	11	10					